

How to make moves with your Motion Sensing Smart Switch

①

Disable your motion sensor when you're sleeping.

Go to the **CYNC™ App**. Under Settings, adjust the Motion Detection Settings. Edit the Device Schedule to deactivate motion detection at night.

②

Keep the motion sensor from turning on lights when natural light fills the room.

Go to the **CYNC App**. Under Settings, adjust Sensor Settings to enable Ambient Light sensitivity.

③

Set brightness levels.

Dim switch to desired level, then turn off. Use Dim button instead of center on/off button to turn on lights at the set level.

④

Control other bulbs and devices with your switch.

Go to **CYNC App**. Add smart lights, switches, and plugs (sold separately) to the same room or group to control them with your switch.

PK-00102838-4

Connect to your Alexa or Google Home device to control your lights with your voice.

Try these voice commands:

Amazon Alexa

Alexa, turn off the living room.

Alexa, good morning.

Alexa, set kitchen to 50%.


Google Home

Hey Google, turn on the lights.

Hey Google, set bedroom to 20%.

Hey Google, I'm leaving.

Touch Controls & Sensors



Air Gap
(When changing light bulbs, pull out to turn off power to the sockets)